

313mm
[12-5/16"]

**Steps for Niche
Cutout Installation:**

1- Secure the template to the wall panel using adhesive tape.

2- Ensure the wall is properly supported, then drill 3/8" holes in all four corners of the cutout area.

3- With the wall still supported, cut along the inside of the dotted line using a blade specifically designed for tile or a fine-tooth saw blade.

Center Mark guides
Do not cut

618mm
[24-3/8"]

Drill bit 3/8" Ø

Cut along the
dotted line

